USER MANUAL

SYTECH®

When technology turns to art

RADIO·CD·MP3

SY·9955

Know these

safety symbols

CAUTION

RISK OF ELECTRIC SHOCK
DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

For Customer Use
Enter below the Serial No. which is located On the bottom of the cabinet. Retain this Information for future reference.

Mode No. _____
Serial No. _____

This "bolt of lightning" indicates uninsulated material within your unit which may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering.

The "exclamation point" calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

Dripping warning:

The product shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the product.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, AND FULLY INSERT.

Ventilation warning:

The normal ventilation of the product shall not be impeded for intended use.

CLASS 1
LASER PRODUCT

PREPARATION FOR USE

Unpacking and Setup

* Carefully remove the unit from the display carton and remove all packing material from the unit itself.

* Remove any descriptive labels that may be found on either the front or top cabinet of the unit. Do not remove any labels located on either the back or button cabinet of the unit.

* Press the CD door OPEN Button to open the CD compartment door. There is a white card in the CD compartment which is intended to prevent the CD pickup from moving during shipment of the product, Remove this card from the CD compartment before use.

Power Supply

Using AC power

1.Check if the power voltage, as shown on the type plate located on the bottom of the set, corresponds to your local AC power supply. If it does not , consult your dealer or service centre.

2.Connect the power cord to the AC socket inlet and the wall outlet. the power supply is now connected and ready for use.

3.To switch off completely, unplug the power cord from the wall outlet.

• Unplug the power cord from the wall outlet to protect your set during heavy thunderstorms.

Batteries (not included)

Open the battery compartment and insert six batteries, type LR14, UM-2 or C-cells, (preferably Alkaline) with the correct polarity as indicated by the + and - symbols inside the compartment

Batteries contains chemical substances, so they should be disposed of properly.

Incorrect use of batteries can cause electrolyte leakage and will corrode the compartment or cause the batteries to burst. Therefore:

- Do not mix battery types: e.g. alkaline with carbon Zinc. Only use batteries of the same type for the set.
- When inserting new batteries, do not try to mix old batteries with new ones. Remove the batteries if the set is not be used for a long time.



1. LEFT&RIGHT SPEAKER
2. REPEAT/TIME/PROGRAM BUTTON
3. USB JACK
4. POWER BUTTON
5.FUNCTION SELECT
6. LCD DISPLAY
7. STANDBY
8. PLAY/PAUSE BUTTON
9. CD DOOR OPEN/CLOSE BUTTON
10. STOP BUTTON
11. NEXT BUTTON
12. BACK BUTTON
13. AC SOCKET
14. FM ANTENNA
15. AUX JACK
16. PHONES JACK
17. VOLUME+ BUTTON
18. VOLUME- BUTTON
19. BATTERY DOOR

Top and front panels (See 1)

1. LEFT&RIGHT SPEAKER

2. REPEAT/TIME/PROGRAM BUTTON
Repeat a track CD/MP3/USB program.
- Repeat mode : repeat ->repeat all-> repeat album ->normal

-In standby mode, to setup the time of the unit.
-Program and review programmed track numbers.
-In the working status, push down this button can on CD/MP3 / USB/RADIO for programming.

3. USB JACK
-To listen to your USB with MP3 music files.

4. POWER BUTTON
-Press power button to turn on/off power.

5. FUNCTION SELECT
-Select source of sound CD/USB/BLUE /AUX/RADIO.

6. LCD DISPLAY
- Show the FM dial frequency.
- Show the number of tracks.

7. STANDBY INDICATOR

8.PLAY/PAUSE BUTTON
-Start or pause MP3/CD/USB play
-In radio mode, press the play/pause button enter the automatic channel surfing mode.

9. CD DOOR OPEN/CLOSE BUTTON
- Press here to open/close the CD door.

10. STOP BUTTON
- Stop CD/MP3/USB playback; erase a CD program.

11.NEXT BUTTON
-To setup the time standby state NEXT track selection.
- Press and hold more than 1.5 sec forward search intra track.
- The radio in the mode, Press NEXT will enter the high-end manual channel surfing mode.

12.BACK BUTTON
-To setup the time standby state BACK track selection.
- Press and hold more than 1.5 sec BACK search intra track.
-The radio in the mode, Press BACK will enter the low end of the manual channel surfing mode.

13. AC SOCKET
- Inlet for power cord.

14. FM ANTENNA
-To improve FM reception.

15. AUX JACK
-Push FUNCTION button , select AUX station. play MP3、DISCMAN、WALKMAN AUX insert.
insert when no disc.
NOTE: Please take out the CD disc.

16. PHONES JACK
- 3.5 mm stereo headphone jack.

17.VOLUME+ BUTTON

18. VOLUME- BUTTON

19. BATTERY DOOR
- To open battery compartment

USE CLOCK

To setup the time of the unit.

1. connect the ac on(The following operation must be in standby mode) .

2. short according to the time button, the time will flashing on the lcd display.

3. Press BACK、NEXT to select the number of the time. you can setup the time format by 12h or 24h.

4. press time button to confirm.

5. then you can set the hour and the minute with the same method of steps 3-4.

6. after setup the unit time, long press the time button can setup the unit begin working time , with the same method of steps 3-4.

Note: after setup the beginning time, the lcd will display the radio/cd/usb/aux mode, Press the BACK or NEXT to choose the mode, then it press time button to affirm, otherwise it play usb or aux mode first.

RADIO

Radio reception

1. Press **FUNCTION** button select RADIO mode .

2.Tune to required station by press BACK/TUNE DN or NEXT/ TUNE UP

Manual Tuning: Press BACK or NEXT and then release within 1 sec.

Auto Tuning: Press and hold the play/pause button enter the automatic channel surfing mode, and to be put automatically sets.

Preset Channel:(FM 30 Preset memories**)**

(1) Press BACK or NEXT Select desired station.

(2) Press play/pause button once , The MEMORY number indicator begins steady in the display.

(3) Press play/pause button repeatedly to select the desired number

(4) Press PROGRAM button to save that station.

(5) Repeat steps (1) to (4) procedures for other stations.

3.After end of program. Press play/pause button repeatedly to start play the frequency that you selected.

4. Press [VOL-]or [VOL +] to adjust the volume.

5.Extend TELESCOPIC ANTENNA to its full length if you are listening to FM broadcasting.

6.Turn off the radio by press FUNC button select other mode or press power button to off the unit.

7.Switch on again after shut down , the memory frequency still exists.

PROGRAM METHOD

(1)Press the [PROGRAM] key at STOP mode, system will go to PROGRAM mode.
-The PRG icon and P01 will blink at 2Hz. This prompts the user to enter the first songs in the program PLAY list.
(2)The user can select the desire tracks by using [NEXT], [BACK] keys.
Once these keys are pressed, the Display will show the selected track.
(3)After select the desired track, press [PROGRAM] key again and it will be stored in the memory.
MP3 Maximum 99 and CD Maximum 20 tracks can be programmed when Repeat steps (2) to (3) procedures.
(4)If press the [STOP] key during the program mode, then the selected TRACKs will be stored in the memory and return to STOP mode (Continuous Play mode)
(5)If press the [PLAY] key during the program mode, it will start the program PLAY mode.
PLAY start from P01 Track

Erasing a program

You can erase the content of the memory by:
- While playing, press STOP button twice.
- Opening the CD door
- Select the other mode.

USE AUX

To listen music with a MP3、discman、walkman·

1. Connect to the AUX .
2. press function selector to AUX, the sound source of the mp3 or discman or walkman will output from the unit.
-Press the volume control to adjust the volume.
-The unit can't control the player.

CD/MP3 PLAYER

CD/MP3 Player

Playing a CD/MP3
This CD-player can play Audio Discs,MP3 CD-R. Do not try to play CD-ROM,CDi,VCD,DVD or computer CD.
1. Press function button to CD state.

2.to open the cd door, press cd open button.

3.insert a mp3/cd or cd-r 、with the printed side facing up and press cd door gently to close.

4.Press play/pause on the set to start playback.

5. Press the pause button to pause play, press the play button back playing.

6.to stop cd playback , press stop.
note: cd/mp3 play will also stop when:
-you open the cd compartment;
-you select radio sound source;
-the cd/mp3 has reached to the end.
selecting a different track.
during playback you can use back or next to select a particular track.
- If you have selected a track number in the stop or pause position, press play to start playback.
- Press next once briefly for the next track, or press repeatedly until the desired track number appears in the display.
- Press back once briefly to return to the beginning of a current track.
- Press back more than once briefly for a previous track.

finding a passage within a track

1.Press and hold down back or next. the cd is played at high speed.

2.when you recognize the passage you want release back or next.
→ normal playback resumes.
different play modes: repeat
repeat - play the current track continuously.

repeat all-plays the entire cd continuously.
playing tracks in random order after press the random button, the tracks will be played in random order.

Playing a USB

USB Audio functions
1)press function button or stop usb button to choose the usb state.

2) PLAY/PAUSE

3) NEXT, BACK Skip search

4) Program Track(MP3 99 Track, CD 20 Track)

5)Repeat mode : repeat ->repeat all-> repeat album ->normal

6) Maximum Folder : 99 Folders

7) Maximum File : 999 Files

*Notice :
-When the unit has not the disc, inserting the usb card will automatically read usb card, it read the USB first while having the USB.

-The unit don't support the HDD all and the portion USB with MP3 player.

Note: at the mode of CD/MP3/USB, the lcd will display the number of song or the song playing time. if at the mode of aux, the lcd will display the symbol of aux or the unit time.

MAINTENANCE & SAFETY

Precautions & General Maintenance

- Place the set on a hard and flat surface so that the system does not tilt.
- Do not expose the set, batteries or CDs to humidity, rain, sand or excessive heat caused by heating equipment or direct sunlight.
- Do not cover the set. Adequate ventilation with a minimum gap of 6 inches between the ventilation holes and surrounding surfaces is necessary to prevent heat build-up.
- The mechanical parts of the set contain self-lubricating bearings and must not be oiled or lubricated.
- To clean the set, use a soft dry cloth. Do not use any cleaning agents containing alcohol, ammonia, benzene or abrasives as these may harm the housing.



CD player and CD handling

- The lens of the CD player should never be touched!
- Sudden changes in the surrounding temperature can cause condensation to form and the lens of your CD player to cloud over. Playing a CD is then not possible. Do not attempt to clean the lens but leave the set in a warm environment until the moisture evaporates.
- Always close the CD door to keep the CD compartment dust-free. To clean, dust the compartment with a soft dry cloth.
- To clean the CD, wipe in a straight line from the centre towards the edge using a soft, lint-free cloth. Do not use cleaning agents as they may damage the disc.
- Never write on a CD or attach any stickers to it.



TROUBLESHOOTING

Troubleshooting

If a fault occurs, first check the points listed below before taking the set for repair.
Do not open the set as there is a risk of electric shock.
If you are unable to remedy a problem by following these hints, consult your dealer or service center.

WARNING: Under no circumstances should you try to repair the set yourself, as this will invalidate the warranty.

– Problem
• Solution

No sound /power

– Volume not adjusted
• Adjust the VOLUME

– power cord not securely connected
• Connect the AC power cord properly

– Batteries dead/ incorrectly inserted
• Insert (fresh) batteries correctly

Display does not function properly / No reaction to operation of any of the controls

– Electrostatic discharge
• Switch off and unplug the set. Reconnect after a few seconds

no disc indication

– No CD/MP3 inserted
• Insert a CD,MP3, CD-R.

– CD badly scratched or dirty
• Replace/ clean CD, see Maintenance

– CD-R、is blank or the disc is not finalized
• Use a finalized CD-R.

CD/MP3/USB playback does not work

– **CD/MP3/USB badly scratched/dirty**
• **Replace/clean CD/MP3/USB (see maintenance)**

– Laser lens steamed up
• Wait until lens has adjusted to room temperature

The CD/MP3 skips tracks

– **CD/MP3 damaged or dirty**
• **Replace or clean CD/MP3**

– Program is active
• Quit Program mode(s)

Environmental information

We have done our best to reduce the packaging and make it easy to separate into 3 materials: cardboard, paper pulp and expandable polyethylene.
Your set consists of materials which can be recycled if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging, dead batteries and old equipment..

TECHNICAL SPECIFICATIONS

GENERAL

Power Requirement .....AC 110/220V~50/60Hz,SET AT 220V
Power consumption .....AC 13.5 Watts

Dimensions.....Appro. 204 mm(L)x200 mm(W) x120 mm(H)

Operation temperature.....+5 ℃ - +35℃

RECEIVER SECTION

Receiving Bands.....FM ST.

Tuning Range..... FM:88-108MHz

COMPACT DISC SECTION

Optical Pickup..... .3-Beam Laser

Frequency Response.....100Hz - 16KH z

AUDIO SECTION

Power output .....Maximum 1 Watt x 2

Headphone Impedance .....4 ~ 32 Ohms

ACCESSORIES

Instruction Booklet.....1

Ac line cord.....1

DECLARATION OF CONFORMITY
Manufacturer Name: Satyatrade S. L.
Address: Pol.Ind.La Raya. C/ Guadalquivir, 2.
Camarma de Esteruelas, 28816 Madrid
Tel: 902 430 967
Fax: 91 8864285
NIF: B83254763
Manufacturing country: China
Description: CD/MP3 player
Sytech® SY-9955 complies with the following directives:

EMC Standard: Directive 2004/108/CE

LVD Standard: 2006/95/EC

Signed: Ajeet Nebhwani Utamchandani
Sole Administrator